




极蜂随身手电筒使用说明书

The User Guide for the BEEBEST Portable Flashlight

使用产品前请仔细阅读本说明书, 并妥善保管

Please read this user guide carefully before using and
retain documentation for future reference

| 产品简介



• 配件说明



挂绳 x 1



7号碱性电池 x 3



说明书 x 1


| 使用方法

• 安装电池

依图示方向旋开手电筒尾盖，将电池对照正负极依次放入电池夹中，然后按照电池夹箭头所指示的方向放入手电筒筒身内，将尾盖拧紧即可。

| 使用方法

- 安装电池



注意：请使用 7 号干电池。

- 开启手电筒

重按手电筒底部按键，即可开启手电筒。



如需关闭手电筒，再次重按底部按键即可。

| 使用方法

• 模式切换

开机状态下,轻按底部按键,可以循环切换光源模式。

初次开启时默认为高亮模式。

光源模式依次循环为:高亮模式→低亮模式→爆闪模式。

注意:关机状态下,重按底部按键进行开关机的操作,每次开启都会切换到下一种模式。

| 基本参数

产品型号: F1

产品尺寸: $\varnothing 33 \times 111.7\text{mm}$

产品净重: 126g

电池类型: 7号干电池 x 3

续航时间: 4.5H/2H(低/高亮)

挡 位: 低亮/高亮/爆闪

最大射程: 130m

典型光通量: 250lm

工作温度: $-20\sim 50^{\circ}\text{C}$

光杯材质: 塑胶

主体材质: 铝合金

| 电子电气产品有害物质声明

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴 联苯 (PBB)	多溴 二苯醚 (PBDE)
主体	○	○	○	○	○	○
配件	○	○	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。

○：表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572-2011 规定的限量要求以下。

×：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572-2011 规定的限量要求。



• 环保使用期限说明

该环保使用期限指在正常使用条件下，极蜂随身手电筒及其附件产品含有的有毒有害物质或元素不会外泄，以及电子信息产品用户使用该产品时不会对环境造成严重污染或对其人身、财产造成严重损害的期限。

| 警告

1. 本产品严禁私自拆开除尾盖外的其他部分，避免可能造成其他危险。
2. 严禁任意拆解、挤压、穿刺、短路本产品或投入水、火中或暴露于温度高于 50°C (122°F) 的环境中。
3. 由于手电筒光线太强，请勿给儿童玩耍及对人眼照射，以免对眼睛造成伤害。

| 保养注意事项

手电筒使用保养不当，可能出现手电筒长明、断火、开关不灵、跑电、镀层脱落等故障。

1. 在使用手电筒后请及时用软布擦干，以防止在雨雪天使用，或湿气和手汗渗入后，导致手电筒的镀层脱落或生锈。
2. 请勿将手电筒放在热炕上或是火炉旁，避免煤烟蒸熏，否则手电筒易发生跑电。
3. 请勿在太阳下暴晒。
4. 避免反复爆闪。

| 手电筒保修政策

• 保修政策

极蜂随身手电筒产品售后服务严格依据《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》实行售后三包服务,服务内容如下:

在三包有效期内,您可以依照本规定免费享受退货、换货、维修的服务。

1. 签收次日起 7 日内无理由退货(电商渠道购买),由用户承担物流费用;
2. 本产品出现《产品性能故障表》所列性能故障的情况,经本公司检测确定后,可以享受如下服务:

服务类型	服务政策
退货或换货	自签收次日起 7 天内产品质量原因
换货或维修	自签收次日起 8~15 天内产品质量原因
维修	自签收次日起 1 年内产品质量原因

• 产品性能故障表

名称	性能故障
极蜂 随身 手电筒	因结构或材料问题造成壳体断裂破损
	新品无法开机或无法正常使用
	无法正常切换模式

| 手电筒保修政策

• 非保修政策

产生以下情况的(但不仅限于下列情况),属于非保修范围,需要付费维修:

1. 已超过三包有效期限;
2. 不可抗力因素造成的损坏;
3. 不符合《产品性能故障表》所列性能故障的情况;
4. 因人为原因导致本产品及其配件产生《产品性能故障表》所列性能故障;
5. 未按《使用说明书》的要求使用、保养及调整造成的任何损坏;
6. 未经过本公司授权的人员私自拆动、修理、改装、误用、滥用、进液、事故、使用非原装的配件所造成的故障或恶意损坏保修卡内容、机体信息,包括模糊破坏、自行撕毁、篡改等;
7. 其他非产品本身设计、制造、质量等问题而导致的故障和损坏;
8. 销售至中国大陆地区的产品,只享受中国大陆地区全国联保服务。

| 产品三包凭证

经销商用/用户保存

客户姓名(先生/小姐)

联系电话

客户地址

邮政编码

产品型号

产 地

购机商店

商店地址

商店联系电话

邮政编码


购机日期

发票号码

附 件

购机单位签章

| Product Introduction



• Accessories



Lanyard x 1



Alkaline Battery 7 x 3



The User Guide x 1


| How to Use

• Battery installation

Unscrew the tail cover of the flashlight according to the direction shown in the figure, put the battery into the battery clamp one by one, then put the battery into the flashlight body according to the direction indicated by the battery clamp arrow, then tighten the tail cover.

| How to Use

- Battery installation



Note: Please use battery 7.

- Power On

Press the button heavily at the bottom and the flashlight will be on.



Press the bottom button heavily again and it will be off.

| How to Use

- **Modes change**

Press the bottom button lightly when the flashlight is on, and the light mode will be switched in circles.

The default mode is high lightness for the initial start.

The light mode will be switched in circles as: high lightness mode → low lightness mode → flash mode.

Note: It will be switched on and off when the bottom button is pressed heavily as it is off, and the next mode will start once it is switched every time.

| Basic Specification

Model: F1

Item Size: Ø33 x 111.7mm

Net Weight: 126g

Battery Type: Battery 7 x 3

Run-time: 4.5H/2H(Low/High)

Range: Low/High/Flash

Max Lighting Distance: 130m

Lumens: 250lm

Working Temperature: -20~50°C

Light Cup Material: Plastic

Main Body: Al Alloy

| Warnings

1. It's not allowed to disassemble other parts of the product except the tail cover without permission to avoid other hazards.
2. Disassembling, crushing, stabbing, circuiting, throwing the product into water or fire are forbidden.
Do not expose it in the environment over 50°C(122°F).
3. Please keep it out of reach of children.
Do not shine it to eyes.

| Maintenance

If the maintenance of the flashlight is not proper enough, the following problems may happen: unable to power off/on, unable to change flexibly, electric leakage or plating fall-off & etc.

1. After using, please remember to dry up the flashlight with soft cloth to avoid plating fall-off or getting rusty caused by the moisture and sweat from the hands, especially on rainy or snowy days.
2. Please do not leave the flashlight on the heated floor, heated bed or near the stove. Keep it away from soot and steam. Otherwise, it will cause electric leakage.
3. Protect it from sunlight.
4. Avoid repeat flash.

服务电话：400-699-8608

服务网址：www.ifengyu.com

执行标准：Q/XAFY0002-2018

制 造 商：西安蜂语信息科技有限公司

地 址：陕西省西安市高新区丈八街办陕西省
科技资源统筹中心 A 区 506 室

Customer service tel.: 400-699-8608

Website: www.ifengyu.com

Executive standard: Q/XAFY0002-2018

Manufacturer: Xi'an Fengyu Information
Technology Co.,Ltd.

Address: Room A-506, SSTRC, Zhangba Subdistrict
Office, High-tech Zone, Xi'an, Shaanxi